

HOW TO MEASURE

JOBST FarrowWrap® RTW Legpiece Size Chart

		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Legpiece						
C	Calf	36-43 cm	42-50 cm	48-58 cm	53-63 cm	58-68 cm
B	Ankle	21-25 cm	25-30 cm	30-36 cm	36-42 cm	42-50 cm
A-D	Regular	35-39 cm	37-41 cm	39-43 cm	41-45 cm	42-46 cm
A-D	Tall	40-44 cm	42-46 cm	44-48 cm	46-50 cm	47-51 cm

Length A-D = Floor to 2 finger widths below crease of knee. Measure posteriorly FOLLOWING contour of leg.

JOBST FarrowWrap® RTW Footpiece size chart

		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Footpiece						
A'	Mid-foot	22-24 cm	25-27 cm	28-30 cm	31-34 cm	35-40 cm
X	Regular	15-17 cm	16-19 cm	18-20 cm	19-22 cm	21-24 cm
X	Tall	18-20 cm	20-22 cm	21-23 cm	23-25 cm	25-27 cm

The length is measured from the most posterior aspect of the heel to the base of the 5th toe

JOBST FarrowWrap® RTW Thighpiece size chart

		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Thighpiece						
G	Groin	60-70 cm	65-75 cm	70-80 cm	75-90 cm	85-100 cm
E	Above Knee	47-52 cm	53-59 cm	60-66 cm	67-73 cm	74-80 cm
E-G	Short	16-20 cm	16-20 cm	16-20 cm	16-20 cm	16-20 cm
E-G	Regular	21-26 cm	21-26 cm	21-26 cm	21-26 cm	21-26 cm
E-G	Tall	27-31 cm	27-31 cm	27-31 cm	27-31 cm	27-31 cm

Length E-G = Measure MEDIANLY from just above patella to the groin. Follow outer contour of any skin folds/lobules.